

Heavy Truck Codes



» Freightliner Cascadia

For many years Strattec included listings of popular types of large trucks in their yearly catalogs. Approximately 20 years ago another company began the distribution of large truck lock components and information on key blanks and key code series by vehicle became less available.

Fortunately many large trucks continue to use the same Strattec codes year after year but there are some exceptions. Freightliner began using a new FT1001-FT3000 code series in 2003. Kenworth and Peterbilt began using a P0001-P1500 series in 2011 and International trucks began using a new I001-I1680 in 2017. Some cab forward (CF) truck models are actually rebadged import models and do not use Strattec key blanks or key codes.

The following list shows which key blanks and key codes are used by each popular large truck model. Please contact Locksmith Ledger either with any errors or omissions you may discover or if you require key cutting information for any key codes listed. or many years Strattec included listings of popular types of large trucks in their yearly catalogs. Approximately 20 years ago another company began the distribution of large truck lock components and information on key blanks



» Caterpillar Excavator

and key code series by vehicle became less available.

Fortunately many large trucks continue to use the same Strattec codes year after year but there are some exceptions. Freightliner began using a new FT1001-FT3000 code series in 2003. Kenworth

and Peterbilt began using a P0001-P1500 series in 2011 and International trucks began using a new I001-I1680 in 2017. Some cab forward (CF) truck models are actually rebadged import models and do not use Strattec key blanks or key codes.

The following list shows which key blanks and key codes are used by each popular large truck model. Please contact Locksmith Ledger either with any errors or omissions you may discover or if you require key cutting information for any key codes listed. ■■

VEHICLE	SERIES	BLANK	YEARS
AUTOCAR			
(all)	D225-D814	1970AM	1995-2018
	N225-N814	1970AM	1995-2018
BERING			
(all)	H001-H1000	X187	1999-2001
CATERPILLAR			
(all)	Z001-Z262	1588	2011-2018
FREIGHTLINER			
Cascadia	FT1001-FT3000	1588	2007-2018
Century	fl001-fl262	1588	1997-2003
	Z001-Z292	1588	1997-2003
	FT1001-FT30001	588	2003-2018
Class 6/7	D225-D814	1980AM	1995-2018
Class 8	H601-H1100	1098X	1981-2018
Columbia	FT1001-FT3000	1588	2004-2006
HINO			
Standard	K001-K9000	X137	1985-1988
	G001-G2377	X174	1989-2004
	W2409	X174	1989-2004
	73000-73999	X274	2005-2018
Cab Forward	10001-15000	X217	2016-2018
INTERNATIONAL			
4300	FL001-FL262	1588	2002-2016
	Z001-Z262	1588	2002-2016
	I001-I1680	1529-P	2017-2018
Cab Forward	10100-12283	X244	2004-2018
Class 6/7/8	K001-K1000	1970AM	1981-2018
KENWORTH			
Da-Lite	G101-G598	K1994	1994-2018
Paccar	P001-P1500	P1108	2011-2018
Standard	C250-C499	1098DB	1981-2011
MACK			
All	H601-H1100	1098X	1980-1986
	M000-M221	1098L	1987-1991
CH/CL/LE	M000-M221	1098L	1992-2018

VEHICLE	SERIES	BLANK	YEARS
MR/RD/DM	H601-H1100	1098X	1992-2018
MARMON			
All	H601-H1100	1098X	1981-2018
MITSUBISHI FUSO			
All	H001-H5143	X121	1985-1988
	8100-9113	FU2	1988-1995
	E5001-E7679	X176	1989-2011
	65001-67012	MIT17TE	2012-2018
OSHKOSH			
All	D225-D814	1970AM	1981-2018
	CD225-CD814	1970AM	1981-2018
PETERBILT			
All	C250-C499	1098DB	1981-1998
	G101-G598	K1994	1999-2011
Paccar	P001-P1500	P1108	2011-2018
STERLING			
Standard	FA000-FA1883	1167FD	1998-2009
Acterra	101A501+	1190LN	2000-2009
Bullet	M001-M2618	Y164-PT	2008-2009
Cargo	E2001-E3000	X170	1985-2009
Condor	FL001-FL262	1588	2002-2009
	Z001-Z262	1588	2002-2009
VOLVO			
Standard	K001-K1000	1970AM	1991-1992
	D225-D814	1970AM	1991-2018
	N225-N814	1970AM	1993-2018
	DH6001-DH8000	S60HF-P	1998-2018
	VN000-VN2000	1588	2005-2018
WESTERN STAR			
All	D225-D814	1970AM	1981-2018
	CD225-CD814	1980AM	1999-2018
WHITE			
All	H601-H1100	1098X	1980-1980
	D225-D814	1970AM	1981-1990